
Exquisite Camping

It's called camping

if you can


stay overnight

Mongolian yurt tent



CHOOSE YOUR STRENGTHS

Why Choose US




- Source factory
- Quality assurance
- After-sale warranty
- SOURCE FACTORY
- QUALITY ASSURANCE
- HONEST BUSINESS
- Sufficient stock
- Custom processing
- Fast delivery
- SUFFICIENT SPOT


- CUSTOM PROCESSING
- FAST DELIVERY

Ingenious manufacturing • easy travel


6 Reasons To Choose US

6 reasons to choose us





The Bottom of The Account Can Be Split



The tent and the bottom of the yurt are connected by zipper. After the tent is set up outdoors, open the zipper on the bottom of the tent, and then you can enjoy the outdoor scenery in the tent!

Good Tent Real Stuff



Good tent real stuff

900D encrypted Oxford cloth (beige)

Waterproof index 5000mm

UPF50+ UV protection

First class anti-mildew treatment

280G cotton (khaki)

Waterproof index 3000mm

Durable and durable, wrinkle-resistant

High-quality fabric

900D encrypted Oxford cloth (beige)

Waterproof index 5000mm

UPF50+ UV protection

First class anti-mildew treatment

280G cotton (khaki)

Waterproof index 3000mm

Durable and durable, wrinkle-resistant High-quallity fabric

NAME: Mongolian yurt tent

ACCOUNT MATERIAL: Cotton/Oxford

BOTTOM MATERIAL: Ripstop PVC

ACCOUNT DRY (MM): Main pole: 38mm*1.5mm wall thickness galvanized steel pipe

Door pole: 19mm*1.0mm wall thickness galvanized steel pipe

SPECIFICATION: 3m/4m/5m/6m/7m

DIMENSIONS (M): 3*3*2/4*4*2.5/5*5*3/6*6*3.5/7*7*3.5

STORAGE SIZE (CM): 112*25*25/100*29*29

112*32*32/120*36*36/120*39*39

WEIGHT (KG): 20/30/40/50/60

ACCESSORIES: Wind Rope: 10/12/12/14/16

Floor Mat Nails: 10/12/12/14/16

Wind Rope Nails: 10/12/12/14/16

....

NAME:	Mongolian yurt tent
ACCOUNT MATERIAL:	Cotton/Oxford
BOTTOM MATERIAL:	Ripstop PVC
ACCOUNT DRY (MM):	Main pole: 38mm*1.5mm wall thickness galvanized steel pipe Door pole: 19mm* 1.0mm wall thickness

^{*} Manual measurement of size and weight, a little error.

All are taken in kind, with a little color difference.

	galvanized steel pip
SPECIFICATION:	3m/4m/5m/6m/7m
DIMENSIONS (M):	3*3*2/4* 4*2. 5/5*5*3/6*6*3. 5/7*7*3. 5
STORAGE SIZE (CM):	112**25*25/100*29*2 12*32*32/120*36*36/120*39*399
WEIGHT (KG):	20/30/40/50/60
ACCESSORIES:	Wind Rope: 10/12/12/14/16 Floor Mat Nails: 10/12/12/14/16 Wind Rope Nails: 10/12/12/14/16


Learn More Product Analysis

Ingenious manufacturing · easy travel

Learn more product analysis








ACCESSORIES INFORMATION




Storage bags and tents



Detail craft

Detail Craft




Iron support rod

Iron Support Rod



Chimney fire cloth





Outer curtain buckle



Smooth zipper

Smooth zipper



Door & window breathable mesh

Outer curtain buckle

Door & window breathable mesh

Scenario Shows


Scenario shows



Don't live up to the night, the moonlight and the evening wind, Let the time of Mercedes-Benz stop in the tenderness of this room



Go all the way to explore the sun, moon, mountains and sea in nature






Installation Notes

Installation notes

STEP1


Lay the tent flat, stretch it all around, and drive into the ground nails



STEP2

Hold up the main pole







STEP 1

Pay the rent flat, stretch it all around, and drive into the ground nails

STEP 2

Hold up the main pole

STEP 3

Raise the door pole

STEP 4

Tighten the wind rope around and drive in the wind rope nails

Maintenance Instructions

Ingenious manufacturing · easy travel

Maintenance Instructions

STORAGE	Store dry to prevent mildew. If the canvas is stored in a humid environment for a long time, mildew will occur. Please smooth the tent to dry completely after encountering water before storing it.
CARE	If there is slight mildew, please use diluted white vinegar + water 5:1 mixed solution with a soft brush to wipe, and then rinse thoroughly with water. Avoid detergent soaps that contain strong acids or alkalines, as this will affect the waterproofing treatment.
PRECAUTIONS	The canvas can burn, please keep it away from open flames to avoid accidents.
SUPPORT ACCOUNT	The new tent needs to go through the maintenance action to improve the waterproof function. It is recommended to set up the tent correctly and spray the surface of the tent fabric with water before using the spring tent for the first time. Do not spray strongly. Wait for it to dry and store.
PRECAUTIONS	When camping on gravel or dirt ground, please use [Ground Cloth] together to ensure that the tent will not be damaged and prolong the service life of the tent.
CLEAN	Regularly clean the zipper with water to maintain its smoothness: Do not use soap or any chemical cleaner to clean the tent to damage the waterproof layer of the cloth, just clean water and soft hair.
BEFORE STORAGE	Make sure that the tent is completely dry before storing, and carefully unpack and fold it carefully to ensure that the tent is not attached to sand.

STORAGE

Store dry to prevent mildew. If the canvas is stored in a humid environment for a long time, mildew will occur. Please smooth the tent to dry completely after encountering water before storing it.

CARE	If there is slight mildew, please use diluted white vinegar + water 5:1 mixed solution with a soft brush to wipe, and then rinse thoroughly with water. Avoid detergent soaps that contain strong acids or alkalines, as this will affect the waterproofing treatment.
PRECAUTIONS	The canvas can burn, please keep it away from open flames to avoid accidents.
SUPPORT ACCOUNT	The new tent needs to go through the maintenance action to improve the waterproof function. It is recommended to set up the tent correctly and spray the surface of the tent fabric with water before using the spring tent for the first time. Do not spray strongly. Wait for it to dry and store.
PRECAUTIONS	When camping on gravel or dirt ground, please use [Ground Cloth] together to ensure that the tent will not be damaged and prolong the service life of the tent.
CLEAN	Regularly clean the zipper with water to maintain its smoothness: Do not use soap or any chemical cleaner to clean the tent to damage the waterproof layer of the cloth, just clean water and soft hair.
BEFORE STORAGE	Make sure that the tent is completely dry before storing, and carefully unpack and fold it carefully to ensure that the tent is not attached to sand.